

30L - Corrosive Substance Storage Cabinet

SC0308

Standard Features

- ✓ Double walled sheet steel construction with a 40mm thermic air barrier
- ✓ High capacity liquid tight sump to contain spills - 150mm deep
- ✓ Self-closing, close fitting doors held shut by catches at 2 points. The doors do not open inwards and are capable of being opened from within the cabinet
- ✓ Built in flash arrestors and vent openings (for mechanical ventilation systems)
- ✓ Strong fully adjustable shelving perforated for free air movement, 100mm adjustment increments
- ✓ Sequential door closing system
- ✓ Stainless steel pin with continuous hinging for strength and reliability
- ✓ State of the art powder coat finish for high durability and performance
- ✓ PVC spill trays on shelves for corrosion protection
Distinct safety signs and directions that comply with AS 1216 and AS 1319
- ✓ Designed and manufactured in full conformance to AS 3780:2023 - The storage and handling of corrosive substances



SC0308 Specification

| Dimensions (mm) | | | |
|-----------------|-----|-----|-----|
| | H | W | D |
| External | 800 | 500 | 450 |
| Internal | 553 | 418 | 370 |

| | |
|----------------------|---------|
| Shelf Levels | 2 |
| Max Capacity | 30L |
| Sump Capacity | 23L |
| Weight (kg) | 33.0 kg |

