

15L - Oxidising Agent Storage Cabinet

SC015A

Standard Features

- ✓ Double walled sheet steel construction with a 40mm thermic air barrier
- ✓ High capacity liquid tight sump to contain spills - 150mm deep
- ✓ Self-closing, close fitting doors that automatically release in the event of a build-up of pressure within the cabinet
- ✓ Built in flash arrestors and vent openings (for mechanical ventilation systems)
- ✓ Strong fully adjustable shelving perforated for free air movement, 100mm adjustment increments
- ✓ Sequential door closing system
- ✓ Stainless steel pin with continuous hinging for strength and reliability
- ✓ State of the art powder coat finish for high durability and performance
- ✓ Distinct safety signs and directions that comply with AS 1216 and AS 1319
- ✓ Designed and manufactured in full conformance to AS 4326:2008 - The storage and handling of oxidising agents.
- ✓ Fully adjustable shelving



SC015A Specification

Dimensions (mm)			
	H	W	D
External	500	350	300
Internal	253	268	220

Shelf Levels	1
Max Capacity	15L
Sump Capacity	8.8L
Weight (kg)	21.0 kg

