

250L - Corrosive Substance Storage Cabinet

SC3008

Standard Features

- ✓ Double walled sheet steel construction with a 40mm thermic air barrier
- ✓ High capacity liquid tight sump to contain spills - 150mm deep
- ✓ Self-closing, close fitting doors that latch at 2 points
Built in flash arrestors and vent openings (for mechanical ventilation systems)
- ✓ Strong and fully adjustable shelving perforated for free air movement, 100mm adjustment increments
- ✓ Sequential door closing system
- ✓ Stainless steel pin with continuous hinging for strength and reliability
- ✓ State of the art powder coat finish for high durability and performance
- ✓ Distinct safety signs and directions that comply with AS 1216 and AS 1319
- ✓ PVC spill tray on shelves for corrosion protection
- ✓ Designed and Manufactured in full conformance to AS 3780:2008 - The storage and handling of corrosive substances



SC3008 Specification

Dimensions (mm)			
	H	W	D
External	1540	750	750
Internal	1315	660	660

Shelf Levels	2 + Base
Max Capacity	250L
Sump Capacity	59L
Weight (kg)	125kg

