

250L - Organic Peroxide Storage Cabinet

SC25052

Standard Features

- ✓ Stainless steel pin with continuous hinging for strength and reliability
- ✓ Strong fully adjustable shelving perforated for free air movement, 100mm adjustment increments
- ✓ High capacity liquid tight sump to contain spills - 150mm deep
- ✓ State of the art powder coat finish for high durability and performance
- ✓ Built in flash arrestors and vent openings (for mechanical ventilation systems)
- ✓ Self-closing, close fitting doors held shut by catches at 2 x points
- ✓ Sequential door closing system
- ✓ Double walled sheet steel construction with 40mm thermic air barrier
- ✓ Distinct safety signs and directions that comply with AS1216 and AS1319
- ✓ Designed and Manufactured in full conformance to AS2714-2008 - The storage and handling of organic peroxides.
- ✓ Manufactured in Australia
- ✓ Fully adjustable shelving



SC25052 Specification

Dimensions (mm)			
	H	W	D
External	1750	1100	500
Internal	1503	1018	420

Shelf Levels	3
Max Capacity	250L
Sump Capacity	64L
Weight (kg)	123.0 kg

